

Thank you for purchasing easyblinds!

Please read and keep these instructions for future use



*scan here for
more info and
how-to videos* →



Your easydoor blind includes the following:

- 1 sheet of easyblackout fabric
- 1 fastener tape to attach your blind to the door
- 10 fastener stickers
- Pair of straps (pressed together, please separate to use)

STEP 1


Make sure the door is completely clean and dry where you will attach the fasteners. Some cleaning products leave a residue, so rinsing with water after cleaning can help.

Apply the fastener tape above the glass - your blind will attach to this.

Apply one fastener sticker above this tape on the left and one on the right - these are for use with the straps. Press firmly.

PLEASE NOTE

- This fabric can be ironed with a cool iron on the front (not fluffy) side.
- If the fabric becomes damp from condensation or moisture on the window, it should be aired and dried between uses.
- Easyblackout fabric is not washable, but can be wiped with a damp cloth.




STEP 2

Press the easyblackout material against the fastener tape strip.

Separate the pair of straps (these are supplied pressed together).

To open your blind, roll it up and use the straps to hold the roll to the additional sticker above, one on the left and one on the right. The strap will attach to the sticker and to the fabric.

Alternatively your blind can be taken off the door between uses.



SAFETY NOTE: If used with small children, do not place directly over a bed, or where it may be pulled down by a child.